

**Ergonomic Solutions**  
**Soluciones Ergonómicas**  
**Solutions Ergonomiques**

# OWNERS MANUAL MANUAL DEL PROPIETARIO MANUEL D'UTILISATION

## DRUM LOCK/CIERRE DEL TAMBOR/ BOUCHON VERROUILLANT DU BIDON MODEL/MODELO/MODÈLE BLD-80

Contents/Contenido/Contenu			
Warning & Safety Instructions .....	1	Instructions de Fonctionnement .....	1
Advertencias e instrucciones de seguridad ..	1	Assembly Drawing .....	1
Instructions de sécurité et avertissement .....	1	Dibujo de Ensamble .....	1
Operating Instructions .....	1	Shéma D'assemblage .....	1
Instrucciones de uso .....	1		

ENGLISH

ESPAÑOL

FRANÇAIS

### WARNING & SAFETY INSTRUCTIONS

- Do not use security bar to tighten drum lock.
- Ensure drum contents will not chemically react with brass drum lock material.
- Do not overtighten drum lock.
- Do not use for lifting.

### ADVERTENCIAS E INSTRUCCIONES DE SEGURIDAD

- No use la barra de seguridad para apretar el cierre del tambor.
- Asegurese que el conenido del tambor no reaccione quimicamente con el material de latón de cierre del tambor.
- No apriete demasiado el cierre del tambor/
- No use para elevar.

### INSTRUCTIONS DE SÉCURITÉ ET AVERTISSEMENTS

- Ne pas utiliser la barre de sécurité pour serrer les bouchons verrouillants du bidon.
- S'assurer que le contenu du bidon n'aura pas de réactions chimiques avec la matière en cuivre de fermeture du bidon.
- Ne pas trop serrer les fermetures.
- Ne pas utiliser pour elever.

### OPERATION INSTRUCTIONS


Carefully screw drum lock into drum hole taking caution so as not to damage threads. Security bar must be installed with long arm down. End of security bar must be outside lip of drum. Insert padlock into hole in security bar to lock drum.

### INSTRUCCIONES DE USO

Atornille con cuidado el cierre del tambor en la perforación, tomando precaución de no dañar las hebras. La barra de seguridad debe de ser instalada con el brazo largo hacia abajo. El extremo de la barra de seguridad debe sobresalir por fuera del borde del tambor. Inserte el candado en la barra de seguridad a través de la perforación para cerrar el tambor.

### INSTRUCTIONS DE FONCTIONNEMENT

Visser soigneusement le bouchon verrouillant dans le trou du bidon en faisant attention de ne pas endommager les filetages. Les barres de sécurité doivent être installées avec la longue tige vers le bas. L'extrémité de la barre de sécurité doit dépasser du rebord du bidon. Insérer le cadenas dans le trou de la barre de sécurité pour fermer le bidon.



## DRUM LOCK/CIERRE DEL TAMBOR/ BOUCHON VERROUILLANT DU BIDON MODEL/MODELO/MODÈLE BLD-80

## LIMITED WARRANTY

Vestil Manufacturing Corporation ("Vestil") warrants this product to be free of defects in material and workmanship during the warranty period. *Our warranty obligation is to provide a replacement for a defective original part if the part is covered by the warranty, after we receive a proper request from the warrantee (you) for warranty service.*

### Who may request service?

Only a warrantee may request service. *You are a warrantee if* you purchased the product from Vestil or from an authorized distributor AND Vestil has been fully paid.

### What is an "original part"?

An original part is a part used to make the product as shipped to the warrantee.

### What is a "proper request"?

A request for warranty service is proper if Vestil receives: 1) a photocopy of the Customer Invoice that displays the shipping date; AND 2) a written request for warranty service including your name and phone number. Send requests by any of the following methods:

Mail  
Vestil Manufacturing Corporation  
2999 North Wayne Street, PO Box 507  
Angola, IN 46703

Fax  
(260) 665-1339  
Phone  
(260) 665-7586

Email  
sales@vestil.com

In the written request, list the parts believed to be defective and include the address where replacements should be delivered.

### What is covered under the warranty?

After Vestil receives your request for warranty service, an authorized representative will contact you to determine whether your claim is covered by the warranty. Before providing warranty service, Vestil may require you to send the entire product, or just the defective part or parts, to its facility in Angola, IN. The warranty covers defects in the following *original* dynamic components: motors, hydraulic pumps, electronic controllers, switches and cylinders. It also covers defects in *original* parts that wear under normal usage conditions ("wearing parts"): bearings, hoses, wheels, seals, brushes, batteries, and the battery charger.

### How long is the warranty period?

The warranty period for original components is 30 days. The warranty period begins on the date when Vestil ships the product to the warrantee. If the product was purchased from an authorized distributor, the period begins when the distributor ships the product. Vestil may extend the warranty period for products shipped from authorized distributors by *up to* 30 days to account for shipping time.

### If a defective part is covered by the warranty, what will Vestil do to correct the problem?

Vestil will provide an appropriate replacement for any *covered* part. An authorized representative of Vestil will contact you to discuss your claim.

### What is not covered by the warranty?

1. Labor;
2. Freight;
3. Occurrence of any of the following, which automatically voids the warranty:
  - Product misuse;
  - Negligent operation or repair;
  - Corrosion or use in corrosive environments;
  - Inadequate or improper maintenance;
  - Damage sustained during shipping;
  - Collisions or other incidental contacts causing damage to the product;
  - Unauthorized modifications: DO NOT modify the product IN ANY WAY without first receiving written authorization from Vestil. Modification(s) might make the product unsafe to use or might cause excessive and/or abnormal wear.

### Do any other warranties apply to the product?

Vestil Manufacturing Corp. makes no other express warranties. All implied warranties are disclaimed to the extent allowed by law. Any implied warranty not disclaimed is limited in scope to the terms of this Limited Warranty.

